

Antiperspirant Roll-On Soft Touch (O/W)

Cutipure CLR™



FORMULA No. 147.04.0855

Phase	Trade Name	INCI Name	w/w %	Supplier
A	Emulgade NLB	Steareth-2, Ceteareth-12, Stearyl Alcohol, Ceteareth-20, Distearyl Ether	5,00	BASF
	Cetiol CC	Dicaprylyl Carbonate	4,50	BASF
	Xiameter PMX- 200 Fluid 100 cst	Dimethicone	1,50	Dow Corning
B	Water	Water	36,00	
C	Water	Water	30,00	
	Locron S	Aluminum Chlorohydrate	20,00	Clariant
D	Cutipure CLR™	Water, Taraktogenos Kurzii Seed Oil, Nigella Sativa Seed Oil, Leptospermum Scoparium Branch/Leaf Oil, Potassium Lauroyl Wheat Amino Acids, Palm Glycerides, Capryloyl Glycine, Magnolia Grandiflora Bark Extract	3,00	CLR

Manufacture:

Mix A, B and heat up to 80°C separately. Slowly add B to A while stirring. Cool down while stirring slowly and avoid incorporation of air. Premix phase C and stir until completely dissolved. Add C and D below 30°C. Stir until uniform.

pH value: 4,21



The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability tested using a special preservative, but has not been subjected to microbiological challenge tests.