



## Even Skin Tone Ampoule Treatment

SyriCalm™ CLR (PC), Phytosan™ K, Belides™ NP, DayMoist CLR™

FORMULA No. 469.06.1006

Phase	Trade Name	INCI Name	w/w %	Supplier
A	Water	Water	ad 100	
	Dermosoft GMCY	Glyceryl Caprylate	0.70	Dr. Straetmans
	Dermofeel PA-3	Sodium Phytate	0.05	Dr. Straetmans
	Keltrol CG-SFT	Xanthan Gum	0.20	CP Kelco
	Phytocream 2000	Potassium Palmitoyl Hydrolyzed Wheat Protein, Glyceryl Stearate, Cetearyl Alcohol	3.00	Sinerga
B	<b>SyriCalm™ CLR (PC)</b>	Water, Phragmites Communis Extract, Poria Cocos Extract	<b>3.00</b>	<b>CLR</b>
	<b>Phytosan™ K</b>	Water, Glycerin, Glycine Soja (Soybean) Seed Extract	<b>2.00</b>	<b>CLR</b>
	<b>Belides™ NP</b>	Bellis Perennis (Daisy) Flower Extract	<b>2.00</b>	<b>CLR</b>
	Microcare SB*	Water, Sodium Benzoate, Potassium	0.50	Thor GmbH
	<b>DayMoist CLR™</b>	Water, Hydrolyzed Corn Starch, Beta Vulgaris (Beet) Root Extract	<b>1.00</b>	<b>CLR</b>

### Manufacture:

Mix A (predisperse the Xanthan Gum) and heat up to 75°C. Homogenize for 3 minutes and cool down while stirring. Add B in the given order below 30°C and stir until uniform.



The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

\*) This formula has been manufactured and stability tested using a special preservative, but has not been subjected to microbiological challenge tests.