

Triple Face Protection (O/W)



SyriCalm™ CLR (PC), Belides™ NP, Phytosan™ K, St. John`s Wort Oil CLR

FORMULA No. 469.06.1008

Phase	Trade Name	INCI Name	w/w %	Supplier
A	Water	Water	ad 100	
	Dermofeel PA-3	Sodium Phytate	0,10	Dr. Straetmans
	Keltrol CG-T	Xanthan Gum	0,30	CP Kelco
B	Eumulgin SG	Sodium Stearoyl Glutamate	0,25	BASF
	Emulgade Sucro	Sucrose Polystearate, Hydrogenated Polyisobutene	1,50	BASF
	St. John`s Wort Oil CLR	Olea Europaea (Olive) Fruit Oil, Hypericum Perforatum Flower/Leaf/Stem Extract, Tocopherol	1,00	CLR
	Cutina GMS-V	Glyceryl Stearate	1,00	BASF
	Lanette O	Cetearyl Alcohol	1,50	BASF
	Cetiol 868	Ethylhexyl Stearate	4,20	BASF
	Cetiol LC	Coco-Caprylate/Caprates	4,20	BASF
	Cosmedia SP	Sodium Polyacrylate	0,35	BASF
	Copherol F1300 C	Tocopherol	0,50	BASF
C	Microcare SB*	Water, Sodium Benzoate, Potassium Sorbate	0,80	Thor GmbH
	SyriCalm™ CLR (PC)	Water, Phragmites Communis Extract, Poria Cocos Extract	3,00	CLR
	Phytosan™ K	Water, Glycerin, Glycine Soja (Soybean) Seed Extract	2,00	CLR
	Belides™ NP	Bellis Perennis (Daisy) Flower Extract	3,00	CLR
	Citric Acid	Citric Acid	0,18	

Manufacture:

Mix A and stir until completely dispersed. Heat A and B to 80°C - 85°C separately. Add A to B while stirring. Homogenize for 3 minutes by ultra turrax. Cool down while stirring slowly. Add C in the given order, one after another below 30°C and stir until uniform.



The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

*) This formula has been manufactured and stability tested using a special preservative, but has not been subjected to microbiological challenge tests.