

PROJECT NAME : Collagen CLR



FORMULA NAME : Moist Me Collagen Facial Mist

TRIAL CODE : 144.006.05

Lab Formula INCI Supplier

<i>Phase</i>	<i>Material Name</i>	<i>Mixed INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	DEIONIZED WATER	WATER	N.A.	76,5
A	TYLOSE H 4070 NG4	HYDROXYETHYLCELLULOSE	SHIN ETSU	0,1
B	ZEMEA	PROPANEDIOL	DUPONT TATE & LYLE	5,0
B	TRISODIUM CITRATE DIHYDRATE	SODIUM CITRATE	MERCK	0,4
B	HYDROLITE-5	PENTYLENE GLYCOL	SYMRISE	5,0
C	COLLAGEN CLR	SOLUBLE COLLAGEN	CLR	10,0
C	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES BETA VULGARIS (BEET) ROOT EXTRACT WATER	CLR	3,0
				100,0

Operating instructions

Operating Instructions

Add Water, dissolve under stirring (~200rpm) and trickle Tylose slowly into the water. Let it stir for ~ 60 min at max. 100 rpm. Add B in the given order and stir until uniform. Add C one after another and stir until homogenous.

Directions for use:

Hold it about five or six inches (~15cm) away from your face and spritz.

Facial Mist can be used after shaving, cleansing, gym, sun and during travel.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com