



Age-Preventing Eye Care

Maricol S

FORMULA No. 352.003.01

Phase	Trade Name	INCI Name	w/w %	Supplier
A	Purolan IHD	Isohexadecane	2.0	Lanxess
	Tegosoft DEC	Diethylhexyl Carbonate	10.0	Evonik
	Xiameter PMX- 200 Silicone Fluid 100cst	Dimethicone	1.0	Dow Corning
B	Aristoflex AVC	Ammonium Acryloyldimethyltaurate/VP Copolymer	1.2	Clariant
C	Water	Water	ad 100	
	Euxyl PE 9010*	Phenoxyethanol, Ethylhexylglycerin	0.6	Schülke
D	NaOH (10%)	Water, Sodium Hydroxide	0.43	
	Maricol S	Soluble Collagen	5.0	CLR

Manufacture

Mix A and stir. Add B and stir until completely swollen. Mix C, stir until homogenous and add it to AB while stirring slowly. Add D in the given order, one by one and stir until uniform.



The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

*) This formula has been manufactured and stability tested using a special preservative, but has not been subjected to microbiological challenge tests.