

PROJECT NAME : AnnonaSense CLR



FORMULA NAME : Derma IQ Sleep Well Night Care OW

TRIAL CODE : 110.001.01A

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	OLIVEM 1000	CETEARYL OLIVATE SORBITAN OLIVATE	HALLSTAR	3.00
A	OLIWAX LC	CETYL PALMITATE SORBITAN PALMITATE SORBITAN OLIVATE	HALLSTAR	3.50
A	MYRITOL 318	CAPRYLIC/CAPRIC TRIGLYCERIDE	BASF	3.00
A	LANETTE O	CETEARYL ALCOHOL	BASF	3.00
A	CETIOL SB 45	BUTYROSPERMUM PARKII BUTTER	BASF	2.00
A	EUTANOL G	OCTYLDODECANOL	BASF	2.00
B	DEIONIZED WATER	WATER	N.A.	72.80
B	SOLAGUM AX	ACACIA SENEGAL GUM XANTHAN GUM	SEPPIC	1.00
B	ZEMEA	PROPANEDIOL	DUPONT TATE & LYLE	6.00
B	EUXYL PE9010	PHENOXYETHANOL ETHYLHEXYLGLYCERIN	SCHUELKE	0.50
C	ANNONASENSE CLR	PROPOSED INCI: ANNONA CHERIMOLA FRUIT EXTRACT	CLR	3.00
D	PERFUME OIL: I'm In Control	FRAGRANCE	IFF	0.20
				100.00

Operating instructions

Operating Instructions

Predisperse the Solagum while stirring at 1100-1300rpm for 10 minutes. Use a defloculator. Then add other ingredients of B. Heat up A and B to 85°C separately. Add A to B under stirring. Homogenize for 3 minutes by Ultra Turrax and cool down while stirring. Add C below 30°C and stir until uniform. Add D as desired.

Directions for use:

Use every evening on cleansed skin. Gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com