

PROJECT NAME : AnnonaSense CLR



FORMULA NAME : Derma IQ Relax Body Lotion OW

TRIAL CODE : 110.002.01A

### Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER	N.A.	80.55
B	KELTROL CG-BT	XANTHAN GUM	CP KELCO	0.50
B	EUMULGIN SG	SODIUM STEAROYL GLUTAMATE	BASF	0.50
B	EMULGADE SUCRO PLUS	SUCROSE POLYSTEARATE CETYL PALMITATE	BASF	2.00
B	CUTINA GMS-V	GLYCERYL STEARATE	BASF	1.00
B	LANETTE O	CETEARYL ALCOHOL	BASF	1.50
B	CETIOL LC	COCO-CAPRYLATE/CAPRATE	BASF	4.00
B	CETIOL RLF	CAPRYLYL-CAPRYLATE/CAPRATE	BASF	4.00
B	CETIOL J 600	OLEYL ERUCATE	BASF	1.50
B	COPHEROL F 1300 C	TOCOPHEROL	BASF	0.05
B	COSMEDIA SP	SODIUM POLYACRYLATE	BASF	0.40
C	VERSTATIL BOB	BENZYL ALCOHOL CAPRYLYL GLYCOL BENZOIC ACID	EVONIK DR. STRAETMANS	0.80
C	ANNONASENSE CLR	PROPOSED INCI: ANNONA CHERIMOLA FRUIT EXTRACT	CLR	3.00
D	PERFUME OIL: Yuzu Rage	FRAGRANCE	IFF	0.20
				<b>100.00</b>

### Operating instructions

#### Operating Instructions

Heat up A and B to 85°C separately. Add A to B and homogenize with Ultra Turrax. Cool down while stirring and add C in the given order. Add D as desired.

Directions for use:

Apply on the whole body and gently rub into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)