

PROJECT NAME : AnnonaSense CLR™



FORMULA NAME : Derma IQ Skin Relief Toner

TRIAL CODE : 110.004.01A

Lab Formula INCI Supplier

| <i>Phase</i> | <i>Material Name</i> | <i>Mixed INCI</i> | <i>Supplier</i> | <i>% Material</i> |
|--------------|-----------------------|--------------------------------------|-----------------|-------------------|
| A | DEIONIZED WATER | WATER | N.A. | 92.62 |
| A | SEPIMAX ZEN | POLYACRYLATE CROSSPOLYMER-6 | SEPPIC | 0.50 |
| B | BUTYLENE GLYCOL | BUTYLENE GLYCOL | MERCK | 3.00 |
| B | EUXYL PE9010 | PHENOXYETHANOL ETHYLHEXYLGLYCERIN | SCHUELKE | 0.80 |
| B | ANNONASENSE CLR™ | ANNONA CHERIMOLA FRUIT EXTRACT | CLR | 3.00 |
| C | PERFUME OIL: Tilia WS | FRAGRANCE | VOEGELE | 0.08 |
| | | | | 100,00 |

Operating instructions

Operating Instructions

Add Sepimax while stirring and stir for ~10 minutes. Add the ingredients of B in the given order and stir until uniform. Add C as desired.

Directions for use:

Swipe it over your face with cotton pad or gently pat it into your skin with hands.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com