

PROJECT NAME : AnnonaSense CLR™



FORMULA NAME : Pure Balance Bi-Phase Serum

TRIAL CODE : 110.004.07A

### Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER		67.88
A	TRISODIUM CITRATE DIHYDRATE	SODIUM CITRATE	MERCK	0.20
A	MICROCARE SB	WATER SODIUM BENZOATE POTASSIUM SORBATE	THOR	0.60
A	PURICOLOR GREEN U3 FDA (0,1%)	WATER CI 42053 (GREEN 3)	BASF	0.12
A	RHEOCARE XGN	XANTHAN GUM	BASF	0.20
B	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES BETA VULGARIS (BEET) ROOT EXTRACT WATER	CLR	3.00
B	ANNONASENSE CLR™	ANNONA CHERIMOLA FRUIT EXTRACT	CLR	3.00
C	CUTIBIOME CLR	OCTYLDODECANOL LEPTOSPERMUM SCOPARIUM BRANCH/LEAF OIL PIPER NIGRUM FRUIT EXTRACT MAGNOLIA OFFICINALIS BARK EXTRACT	CLR	3.00
C	CETIOL J 600	OLEYL ERUCATE	BASF	13.95
C	CETIOL C 5C	COCO-CAPRYLATE/CAPRATE	BASF	8.00
C	PERFUME OIL: Shaolin	FRAGRANCE	FREY + LAU	0.05
				<b>100.00</b>

### Operating instructions

#### Operating Instructions

Mix A until uniform. Add B in the given order to A and stir. Premix C and add to AB.

Directions for use:

Take a few drops of the serum and gently massage into the skin. Shake before use.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)