

PROJECT NAME : AnnonaSense CLR™



FORMULA NAME : Natural You Jelly Face Scrub for Mixed Skin

TRIAL CODE : 110.006.04A

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER	N.A.	55.79
A	AMAZE XT	DEHYDROXANTHAN GUM	NOURYON	1.00
B	ETHANOL (96%) DENATURED	ALCOHOL DENAT.	BERKEL AHK	15.00
B	GLYCERIN 86%	GLYCERIN WATER	GUSTAV HEESS	5.00
B	PLANTACARE 2000 UP	DECYL GLUCOSIDE	BASF	6.00
B	DEHYTON MC	SODIUM COCOAMPHOACETATE	BASF	5.50
B	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES BETA VULGARIS (BEET) ROOT EXTRACT WATER	CLR	3.00
B	PRORENEW COMPLEX CLR™ NP	LACTOCOCCUS FERMENT LYSATE	CLR	3.00
B	CITRIC ACID (50%) SOLUTION	CITRIC ACID WATER	N.A.	0.51
C	ANNONASENSE CLR™	ANNONA CHERIMOLA FRUIT EXTRACT	CLR	3.00
D	IMERSCRUB 400P GOLD	PERLITE	IMERYS	2.00
E	GRAPEFRUIT OIL	CITRUS PARADISI PEEL OIL	VOEGELE	0.20
				100.00

Operating instructions

Operating Instructions

Mix A and stir until uniform. Add B in the given order with moderate stirring. Add C and stir until uniform. Slowly add D with moderate stirring. Add E as desired.

Directions for use:

apply on the wet face, neck & décolleté. Avoid contact with area around the eyes. Massage thoroughly and rinse-off well. Use two to three times a week

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com