



Biotic Night Lotion OW
I-40.135.06

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	67.160
A	Zemea	Propanediol	Primient Covation LLC	2.500
A	Propylene Glycol	Propylene Glycol	BASF	3.000
A	Sepinov EMT 10	Hydroxyethyl Acrylate/Sodium Acryloyldimethyl Taurate Copolymer	SEPPIC	1.000
A	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	1.000
A	EDETA B Powder	Tetrasodium EDTA	BASF	0.260
B	Myritol 318 MB	Caprylic/Capric Triglyceride	BASF	5.000
B	Tegosoft TN	C12-15 Alkyl Benzoate	Evonik	2.500
B	CutiBiome CLR™	Octyldodecanol Leptospermum Scoparium Branch/Leaf Oil Piper Nigrum Seed Extract Magnolia Officinalis Bark Extract	CLR	3.000
B	Tegosoft OER MB	Oleyl Erucate	Evonik	2.000
C	Euxyl K 900	Benzyl Alcohol Ethylhexylglycerin Tocopherol	Ashland	0.800
C	Ethanol (96%)	Alcohol	Berkel AHK	6.000
C	RonaCare Salicylic Acid	Salicylic Acid	Merck	2.000
D	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.780
E	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.000
				100.000000

Operating Instructions

Mix A and B separately. Add A to B and stir until homogenous or homogenize. Dissolve C and add it while stirring. Adjust pH value to ~4 with D and add E.

Directions for use:

Take a pea-size amount and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com