



Soothing Intimate Gel for Women After Menopause

II-17.469.02_1

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	85.13
A	Euxyl PE 9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
A	Carbopol Ultrez 21	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	Lubrizol	0.50
A	Hispagel 200 Ns	Glycerin Glyceryl Polyacrylate	BASF	5.00
B	SyriCalm™ CLR (PC)	Water Phragmites Communis Extract Poria Cocos Extract	CLR	3.00
B	Lactokine™ Fluid PF-H	Milk Protein	CLR	5.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.57
				100.000000

Operating Instructions

Mix A and stir slowly until completely dispersed. Add B under stirring and adjust pH value to 6.-6.5 with C.

Directions for use:

outside the vagina: take a peasize and apply gently.

inside: apply with hygienic disposable applicator into the vagina before bedtime.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com