



Cleansing Foam Oily Skin  
V-54.469.02A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Rheance One	Glycolipids	Evonik	6.00
A	Tego Betain F 50	Cocamidopropyl Betaine	Evonik	8.00
A	Tego Remo 95 MB	Sorbitan Caprylate Glyceryl Oleate	Evonik	0.55
B	A-Leen 5	Pentylene Glycol	Minasolve	4.00
B	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.80
B	Deionized Water	Water	N.A.	79.30
B	<b>SyriCalm™ CLR (PC)</b>	Water Phragmites Communis Extract Poria Cocos Extract	CLR	1.00
C	Perfume Tilia WS	Fragrance	Voegele	0.15
C	Puricolor Red ARE 33 (0,02%) / Blue ABL9-X FDA (0,01%)	Water Acid Red 33 Acid Blue 9	N.A.	0.20
				<b>100.00000</b>

#### **Operating Instructions**

Mix A and B separately. Add B while stirring. Add C as desired. Fill into pump foam dispenser.

Directions for use:

Apply a small amount of cleansing foam to slightly damp skin in the morning and evening. Gently massage in. Rinse off with warm water.  
Avoid the eye area.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)