

PROJECT NAME : ProRenew Complex CLR™



FORMULA NAME : Balance Me Probiotic Scalp Fluid

TRIAL CODE : 421.027.01A

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER	N.A.	91.37
A	EUXYL PE9010	PHENOXYETHANOL ETHYLHEXYLGLYCERIN	SCHUELKE	0.80
A	PEMULEN TR-1	ACRYLATES/C10-30 ALKYL ACRYLATE CROSSPOLYMER	LUBRIZOL	0.30
B	PHYTODEFENSE CLR™	GLYCINE SOJA (SOYBEAN) OIL DICAPRYLYL ETHER MAGNOLIA GRANDIFLORA BARK EXTRACT LAURYL ALCOHOL	CLR	3.00
B	TEGOSOFT AC	ISOAMYL COCOATE	EVONIK	1.00
B	COPHEROL F 1300 C	TOCOPHEROL	BASF	0.03
C	NAOH (32%)	WATER SODIUM HYDROXIDE	N.A.	0.25
D	PRORENEW COMPLEX CLR™	LACTOCOCCUS FERMENT LYSATE	CLR	3.00
E	PERFUME OIL: Aloe Flower KWS	FRAGRANCE	FREY + LAU	0.25
				100.00

Operating instructions

Operating Instructions

Mix A and stir until completely dispersed. Premix B and add it to A. Homogenize for a short moment and adjust pH value to 5.5-6 with C. Add D while stirring and E as desired. Mix until uniform.

Directions for use:

Apply on the scalp and gently massage.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com