

PROJECT NAME : ProRenew Complex CLR NP



FORMULA NAME : Protect Me Face & Body Spray

TRIAL CODE : 422.007.02A

#### Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	DEIONIZED WATER	WATER	N.A.	82.54
A	ZEMEA	PROPANEDIOL	DUPONT TATE & LYLE	3.00
A	HISPAGEL 200 Ns	GLYCERIN GLYCERYL POLYACRYLATE	BASF	3.00
A	KELTROL CG-T	XANTHAN GUM	CP KELCO	0.10
A	HYDROLITE-5	PENTYLENE GLYCOL	SYMRISE	5.00
B	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES BETA VULGARIS (BEET) ROOT EXTRACT WATER	CLR	3.00
B	PRORENEW COMPLEX CLR™ NP	LACTOCOCCUS FERMENT LYSATE	CLR	3.00
C	NAOH (32%)	WATER SODIUM HYDROXIDE	N.A.	0.16
D	PERFUME OIL: Criste Marine PMF WS	FRAGRANCE	VOEGELE	0.20
				<b>100.00</b>

#### Operating instructions

##### *Operating Instructions*

Mix A and stir until completely dispersed. Add B under stirring and adjust pH value to 5-5.5 with C. Add D and stir until uniform.

Directions for use:

Spray on the face and body after shower or face wash. Apply in the morning and evening on cleansed skin before your usual routine.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)