

## CLR Formulation Concepts

# Luminizing Highlighter Stick

This Luminizing Highlighter comes in stick format and is therefore a perfect product to take it with you in your handbag to refresh your make-up look on the way. It can be used to contour, highlight or touch up the complexion. The highlighter will leave your skin with a radiant and beautifully illuminated look. The combination of **MultiMoist CLR™** and **Vitamin F forte** is perfect to give your skin a moisturized feeling during the day.

### Directions for use:

Can be applied around the eye/eyelid or on the orbital bone for a brighter appearance. Can also be used as a highlighter on the cheekbones, cupid's bow nose, and anywhere else you want a glow effect. Designed to be applied under or on top of make-up.



## Featured Products



### MultiMoist CLR™ – Mapping the moisturization puzzle

MultiMoist CLR™ activates production of the vitamin D receptor (VDR) and promotes the VDR's activation. MultiMoist CLR™ also potentiates the effect of vitamin D. As a consequence the skin becomes more moisturized. By making use of 5 different objective instrumental approaches, the immediate and long term moisturizing properties of MultiMoist CLR™ were convincingly proven. Additionally, the activity of MultiMoist CLR™ was proven in a consumer study, where the subjective improvement of skin moisture content, skin smoothness and the look of skin were confirmed.

MultiMoist CLR™ consists of a powerful synergistic blend of fructooligosaccharides and beta vulgaris (beet) root extract.

**Dosage:** 3.0%  
**pH range:** 3.0–8.0

**INCI Name:** Fructooligosaccharides, Beta Vulgaris (Beet) Root Extract, Water



### Vitamin F forte – Essential fatty acids nourishing skin

Vitamin F forte nurtures, protects and acts as a skin conditioner. It is particularly suitable for the treatment of dry, stressed and sensitive skin, potently supporting the skin in rebuilding and maintaining its natural healthy structure and functionality. Vitamin F forte also has some great benefits for hair. Vitamin F forte contains natural polyunsaturated essential free fatty acids originating from safflower oil, with a particularly high content of linoleic acid.

**Dosage:** 0.5–3.0%  
**pH range:** 3.0–10.0

**INCI Name:** Linoleic Acid, Linolenic Acid

## Luminizing Highlighter Stick\*

385.021.09

PHASE	TRADE NAME	INCI NAME	SUPPLIER	W/W %
A	MIGLYOL PPG 810	PROPYLENE GLYCOL DICAPRYLATE/DICAPRATE	IOI OLEO	20.30
	CERAPHYL 847	OCTYLDODECYL STEAROYL STEARATE	ASHLAND	11.00
	ACTICIRE MB	JOJOBA ESTERS, HELIANTHUS ANNUUS (SUNFLOWER) SEED WAX, ACACIA DECURRENS FLOWER WAX, POLYGLYCERIN-3	GATTEFOSSE	5.00
	LIPOCIRE A PELLETS	C10-18 TRIGLYCERIDES	GATTEFOSSE	5.00
	BIOCHEMICA VITAMIN E NAT.	TOCOPHEROL	HALLSTAR	0.20
	LEXGARD O	CAPRYLYL GLYCOL	INOLEX	1.00
	KAHLWAX 6700 CL SUBSTITUTE	COPERNICIA CERIFERA CERA (CARNAUBA WAX), HELIANTHUS ANNUUS (SUNFLOWER) SEED WAX, POLYETHYLENE, C30-50 ALCOHOLS, MONTAN ACID WAX, SHOREA ROBUSTA RESIN, HYDROGENATED STYRENE/METHYL STYRENE/INDENE COPOLYMER	KAHLWAX	6.50
	TIXOGEL-VSP 1438	CYCLOPENTASILOXANE, CYCLOHEXASILOXANE, QUATERNIUM-90 BENTONITE, PROPYLENE CARBONATE	ECKART	13.00
B	GRANPOWDER USQ	POLYMETHYLSILSESQUIOXANE, HDI/TRIMETHYLOL HEXYLLACTONE CROSSPOLYMER	GRANT INDUSTRIES	5.00
	AGENAFLO OS 9051	ALUMINUM STARCH OCTENYLSUCCINATE	AGRANA	6.00
	SYNAFIL S1050	SYNTHETIC FLUORPHLOGOPITE	ECKART	7.00
	SYNCRYSTAL SUPERNOVA RED	SYNTHETIC FLUORPHLOGOPITE, IRON OXIDES (CI 77491), TIN OXIDE	ECKART	0.50
	SYNCRYSTAL BLUE	SYNTHETIC FLUORPHLOGOPITE, TITANIUM DIOXIDE (CI 77891), TIN OXIDE	ECKART	0.50
	MIRAGE GLAMOUR GOLD	CALCIUM SODIUM BOROSILICATE, TITANIUM DIOXIDE (CI 77891), TIN OXIDE	ECKART	7.00
	MIRAGE GLAMOUR RED	CALCIUM SODIUM BOROSILICATE, TITANIUM DIOXIDE (CI 77891), TIN OXIDE	ECKART	8.00
C	MULTIMOIST CLR™	FRUCTOOLIGOSACCHARIDES, BETA VULGARIS (BEET) ROOT EXTRACT, WATER	CLR	3.00
	VITAMIN F FORTE	LINOLEIC ACID, LINOLENIC ACID	CLR	1.00

**Manufacture:**

Heat up A to 80–85°C. Add B and mix until uniform. Add C, stir until homogenous and pour into stick moulds quickly. Cool down.

**Directions for use:**

Can be applied around the eye/eyelid or on the orbital bone for a brighter appearance. Can also be used as a highlighter on the cheekbones, cupid's bow, nose and anywhere else you want a glow effect. Designed to be applied under or on top of make-up.

\* developed & produced by Eckart; [www.eckart.net](http://www.eckart.net)

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

**CLR**

Chemisches Laboratorium Dr. Kurt Richter GmbH  
Sperenberger Straße 3 · 12277 Berlin · Germany  
Tel +49 30 851026-0 · Fax +49 30 851026-85  
[info@clr-berlin.com](mailto:info@clr-berlin.com) · [www.clr-berlin.com](http://www.clr-berlin.com)

