



Night Lifting Eye Care

I-2.290.02

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	79.95
A	Glycerin 86%	Glycerin Water	Gustav Heess	2.00
A	Hydrolite-5	Pentylene Glycol	Cosnaderm	5.00
A	Cosmedia SP	Sodium Polyacrylate	BASF	1.20
B	Cetiol J 600	Oleyl Erucate	BASF	8.00
B	Copherol F 1300 C	Tocopherol	BASF	0.01
C	MPC™ - Milk Peptide Complex	Whey Protein	CLR	0.50
C	JuvenEye CLR™	Bellis Perennis (Daisy) Flower Extract Hieracium Pilosella (Hawkweed) Extract	CLR	3.00
D	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.34
				100.00

Operating Instructions

Mix A and stir until completely soaked. Add B and stir for a short moment. Add C and stir until uniform. Adjust pH value to 6-6.5 with D.

Directions for use:

Take a pea-sized amount and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com