



Firming & Brightening Face Serum OW
I-23.126.01

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	71.8
A	Glycerin 86%	Glycerin Water	Gustav Heess	3.0
A	Hydrolite-5	Pentylene Glycol	Cosnaderm	5.0
A	Rheocare XGN	Xanthan Gum	BASF	0.8
B	Eumulgin SG	Sodium Stearoyl Glutamate	BASF	0.4
B	Lanette O MB	Cetearyl Alcohol	BASF	0.5
B	Cutina HVG	Hydrogenated Vegetable Glycerides	BASF	2.0
B	Cetiol C 5	Coco-Caprylate	BASF	3.0
B	Myritol 318 MB	Caprylic/Capric Triglyceride	BASF	4.0
B	Cetiol LC	Coco-Caprylate/Caprata	BASF	4.0
C	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.0
C	Belides™ ORG	Bellis Perennis (Daisy) Flower Extract	CLR	2.0
C	MPC™ - Milk Peptide Complex	Whey Protein	CLR	0.5
				100.0

Operating Instructions

Mix A and predisperse until homogenous. Heat up A and B to 80°C separately. Add A to B and homogenize for 3 minutes by Ultra Turrax. Cool down while stirring and add C in the given order below 30°C.

Directions for use:

Apply on cleansed skin and massage gently.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com