



Face & Hand Mask OW  
I-31.311.01\_2

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Olivem 1000	Cetearyl Olivat Sorbitan Olivat	Hallstar	3.00
A	Oliwax LC	Cetyl Palmitat Sorbitan Palmitat Sorbitan Olivat	Hallstar	3.50
A	Myritol 312 MB	Caprylic/Capric Triglyceride	BASF	3.00
A	Lanette O MB	Cetearyl Alcohol	BASF	3.00
A	Cetiol SB 45	Butyrospermum Parkii (Shea) Butter	BASF	2.00
A	Eutanol G	Octyldodecanol	BASF	2.00
B	<b>PhytoDefense CLR™</b>	Glycine Soja (Soybean) Oil Dicaprylyl Ether Magnolia Grandiflora Bark Extract Lauryl Alcohol	CLR	3.00
C	Deionized Water	Water	N.A.	69.29
C	Solagum AX	Acacia Senegal Gum Xanthan Gum	SEPPIC	1.00
D	Euxyl PE9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
D	<b>DayMoist CLR™</b>	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	3.00
E	NaOH (10%)	Water Sodium Hydroxide	N.A.	1.41
F	<b>Lactokine™ Fluid PF</b>	Milk Protein	CLR	5.00
				<b>100.00</b>

#### ***Operating Instructions***

Heat up A and premixed phase C to 75°C separately. Add B to A and AB to C under stirring. Homogenize for 3 minutes and stir cold. Add D in this order below 30°C. Adjust pH value to 6.5 with E and add F. Stir until homogeneous.

Directions for use:

Apply over clean skin in a thin layer. After 5 minutes, lightly massage residues into the skin or wipe away with tissue.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)