



Milky Collagen Serum OW
I-32.352.01

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	80.89
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.41
A	Euxyl PE 9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
B	Tegosoft OP	Ethylhexyl Palmitate	Evonik	6.00
B	Tegosoft OS	Ethylhexyl Stearate	Evonik	6.00
B	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	0.90
C	Maricol S	Soluble Collagen	CLR	5.00
				100.00

Operating Instructions

Mix A and B separately. Add A to B while stirring. Add C with moderate stirring.

Directions for use:

Gently massage the serum into the face, neck & décolleté. Apply twice daily.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com