



Hydra Face Fluid OW  
I-38.106.01A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Cosmedia SP	Sodium Polyacrylate	BASF	0.50
A	Cutina PES	Pentaerythrityl Distearate	BASF	1.00
A	Cetiol 868	Ethylhexyl Stearate	BASF	6.00
A	Cetiol CC	Dicaprylyl Carbonate	BASF	1.00
A	Myritol 318 MB	Caprylic/Capric Triglyceride	BASF	1.55
B	Deionized Water	Water	N.A.	80.82
B	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	3.00
C	<b>Ceramide Complex CLR PE-F</b>	Water Phospholipids Sphingolipids	CLR	5.00
C	Euxyl K 900	Benzyl Alcohol Ethylhexylglycerin Tocopherol	Ashland	0.80
D	Perfume Basil & Orange WS	Fragrance	Voegele	0.33
				<b>100.00</b>

#### **Operating Instructions**

Heat up A to 75°C and add B. Homogenize for 3 minutes and cool down while stirring. Add C in this order and stir until uniform. Add D as desired.

Directions for use:

Apply every morning. Take a pea-sized amount and gently massage into the skin (face, neck & décolleté).

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)