



HappyScalp Toner OW
I-4.135.05A

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	82.49
A	Pentylene Glycol	Pentylene Glycol	Cosnaderm	5.00
A	Sepilife NUDE	Sodium Acrylate/Sodium Acryloyldimethyl Taurate Copolymer C15-19 Alkane Polyglyceryl-6 Laurate Polyglycerin-6	SEPPIC	2.80
B	CutiBiome CLR™	Octyldodecanol Leptospermum Scoparium Branch/Leaf Oil Piper Nigrum Seed Extract Magnolia Officinalis Bark Extract	CLR	3.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
B	Nat. Green Tea N45211	Available on request	Carrubba	0.50
B	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.11
D	Puricolor Yellow AYE 23 (0.2%) /Blue ABL9-X FDA (0.05%)	Water Acid Yellow 23 Acid Blue 9	BASF	0.10
				100.00

Operating Instructions

Mix A and stir until homogeneous. Add B in this order and adjust pH value to 6 with C, if necessary. Add D as desired.

Directions for use:

Apply on the face/scalp and gently massage into skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com