



Sleeping Lip Mask OW  
I-48.352.01\_1

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Tego Care 450 MB	Polyglyceryl-3 Methylglucose Distearate	Evonik	3.00
A	Lanette O MB	Cetearyl Alcohol	BASF	2.25
A	Cutina GMS-SE G	Glyceryl Stearate SE	BASF	2.25
A	Tegosoft OER MB	Oleyl Erucate	Evonik	8.00
A	Cetiol OE	Dicaprylyl Ether	BASF	5.00
A	Cetiol SB 45	Butyrospermum Parkii (Shea) Butter	BASF	2.00
A	Keltrol CG-SFT	Xanthan Gum	CP Kelco	0.10
B	<b>Vitamin F forte</b>	Linoleic Acid Linolenic Acid	CLR	1.00
B	Dermofeel Toco 70 non GMO	Tocopherol Helianthus Annuus (Sunflower) Seed Oil	Evonik	0.50
C	Deionized Water	Water	N.A.	65.40
C	Zemea	Propanediol	Primient Covation LLC	5.00
D	Euxyl PE 9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.50
D	<b>Maricol S</b>	Soluble Collagen	CLR	5.00
				<b>100.000000</b>

#### ***Operating Instructions***

Heat up A/C separately to 70-75°C. Add B to A and C to AB while homogenizing. Cool down under stirring. Add D in this order at room temperature and stir until homogeneous.

Directions for use:

Wear generously on the lips before bedtime.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)