



Renewal Lip Mask OW  
I-50.421.01\_3

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	63.03
A	Dermofeel PA-3	Sodium Phytate Water Alcohol	Evonik	0.05
A	Glycerin 86%	Glycerin Water	Gustav Heess	5.00
A	Euxyl PE9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
B	Keltrol CG-SFT	Xanthan Gum	CP Kelco	0.50
B	Emulgade Sucro Plus	Sucrose Polystearate Cetyl Palmitate	BASF	1.80
B	Eumulgin SG	Sodium Stearoyl Glutamate	BASF	0.20
B	Lanette O MB	Cetearyl Alcohol	BASF	3.00
B	Cutina GMS-V	Glyceryl Stearate	BASF	4.00
B	Cetiol CC	Dicaprylyl Carbonate	BASF	5.00
B	Cetiol SB 45	Butyrospermum Parkii (Shea) Butter	BASF	5.00
B	Copherol F 1300 C	Tocopherol	BASF	0.10
B	Myritol 312 MB	Caprylic/Capric Triglyceride	BASF	5.00
C	<b>Vitamin F forte</b>	Linoleic Acid Linolenic Acid	CLR	3.00
D	<b>ProRenew Complex CLR™</b>	Lactococcus Ferment Lysate	CLR	3.00
E	Citric Acid (10%)	Water Citric Acid	N.A.	0.52
				<b>100.00</b>

#### **Operating Instructions**

Mix A and B separately. Heat A and B to 78-80°C separately. Add B,C to A and homogenize for a short time. Cool down under stirring. Add D and stir. Adjust pH value to 5.5-6 with E.

Directions for use:

Wear generously on the lips. After approx. 10 minutes, remove the remnants of the mask with a soft tissue.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)