



As Unique As Me-DIY Face Mask OW
I-6.385.01

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Agenaflo 9050	Corn Starch Modified	AGRANA	88.99
A	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
A	CutiBiome CLR™	Octyldodecanol Leptospermum Scoparium Branch/Leaf Oil Piper Nigrum Seed Extract Magnolia Officinalis Bark Extract	CLR	3.00
B	Eumulgin SG	Sodium Stearoyl Glutamate	BASF	1.00
B	Verdessence Alginate	Algin	BASF	4.01
				100.00

Operating Instructions

Mix A and stir until completely dissolved (finely rub). Add B in this order and stir well until uniform. Fill into appropriate container.

Directions for use:

Fill the powder into a small bowl. Fill water into the dose until to the top edge and add it to bowl. Start mixing with spatula or brush. Stir until uniform and add booster ampoules as desired. Stir until homogeneous. Mask is ready to apply on the face or body. Allow mask to dry for 5-10 minutes and rinse.

For an even skin tone and beautiful glow: 13-32ggt Belides™ NP/Belides™ ORG

For improved skin quality and a balanced skin microbiota: 27ggt ProRenew Complex CLR™

For soothed and perfectly balanced skin: 27ggt AnnonaSense CLR™

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com