



Set Me Free Scalp Fluid OW
I-65.135.02A_1

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	89.62
A	Pemulen EZ-4U	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	Lubrizol	0.25
A	A-Leen 5	Pentylene Glycol	Minasolve	5.00
A	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.00
B	CutiBiome CLR™	Octyldodecanol Leptospermum Scoparium Branch/Leaf Oil Piper Nigrum Seed Extract Magnolia Officinalis Bark Extract	CLR	1.50
C	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.52
D	Perfume Herbs	Fragrance	Voegele	0.10
D	Puricolor Blue ABL9-X FDA (0.2%)	Water Acid Blue 9	BASF	0.01
				100.00

Operating Instructions

Mix A and stir. Add B and homogenize. Adjust pH value to 5.8-6 with C. Add D as desired.

Directions for use:

Take a pea-sized amount and massage into the scalp gently.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com