



Dark Circles Correcting Eye Cream OW
I-68.355.02A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	75.72
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	2.00
A	Verdessence Xanthan	Xanthan Gum	BASF	0.45
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.25
B	Olivem 1000 MB	Cetearyl Oliviate Sorbitan Oliviate	Hallstar	5.00
B	Cetiol C 5C	Coco-Caprylate/Caprata	BASF	4.00
B	Cetiol J 600	Oleyl Erucate	BASF	1.00
B	Lanette O MB	Cetearyl Alcohol	BASF	1.00
B	Cetiol Ultimate	Undecane Tridecane	BASF	1.00
C	Euxyl K 900	Benzyl Alcohol Ethylhexylglycerin Tocopherol	Ashland	0.80
C	JuvenEye CLR™	Bellis Perennis (Daisy) Flower Extract Hieracium Pilosella (Hawkweed) Extract	CLR	3.00
C	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
D	MPC™ - Milk Peptide Complex	Whey Protein	CLR	0.50
E	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.08
F	RonaFlair Balance Blue	Titanium Dioxide Mica Tin Oxide	Merck	1.00
F	RonaFlair Balance Red	Titanium Dioxide Mica Tin Oxide	Merck	1.00
F	Perfume Nat. Creme de Luxe	Fragrance	Frey+Lau	0.20
				100.00

Operating Instructions

Mix A and heat up to 75-80°C. Mix B and heat up to 70-75°C. Add B to A and homogenize for a few minutes. Cool down to room temperature under gentle stirring. Below 30°C add C and D in this order and homogenize for a few minutes. Add E and adjust pH value to 6-6.4 with E. Add F and stir until homogeneous.

Directions for use:

Take a pea-sized amount of the cream and tap into the skin under the eyes in the morning.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com