



Healthy Barrier Night Cream OW
I-86.106.01A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	57.81
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	3.00
B	Axol C 62 Pellets MB	Glyceryl Stearate Citrate	Evonik	2.00
B	Tego Alkanol 1618 MB	Cetearyl Alcohol	Evonik	1.50
B	Tegin M Pellets MB	Glyceryl Stearate	Evonik	2.00
B	Myritol 318 MB	Caprylic/Capric Triglyceride	BASF	16.00
B	Cetiol J 600	Oleyl Erucate	BASF	6.00
B	Cetiol SB 45	Butyrospermum Parkii (Shea) Butter	BASF	2.50
B	Keltrol T Plus	Xanthan Gum	CP Kelco	0.20
C	CutiGuard CLR™	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
C	Ceramide Complex CLR PE-F	Water Pentylene Glycol Phospholipids Sphingolipids	CLR	5.00
C	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.80
D	Perfume Sage Basil nat	Fragrance	Voegele	0.19
				100.00

Operating Instructions

Mix A and B separately and heat up to 78°C. Add B to A and homogenize for 2 minutes. Cool down under stirring. Add C in this order and homogenize for a short moment. Add D ad desired.

Directions for use:

Apply on the face and gently rub in until absorbed.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com