



Probiome Jelly Serum
II-1.385.07

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	87.06
A	Amaze XT	Dehydroxanthan Gum	Nouryon	0.75
B	Verstatil BOB	Benzyl Alcohol Caprylyl Glycol Benzoic Acid	Evonik	1.00
B	Repair Complex CLR™ PF	Bifida Ferment Lysate	CLR	5.00
B	ProRenew Complex CLR™ NP	Lactococcus Ferment Lysate	CLR	3.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.18
D	SynCrystal Fire-Red	Synthetic Fluorphlogopite Iron Oxides	Eckart	0.01
				100.00

Operating Instructions

Stir A until completely dispersed or homogenize with Ultra Turrax. Add C in the given order and adjust pH value to 5 with C. Stir until homogeneous. Add D as desired.

Directions for use:

Take a pea-sized drop and gently massage into the skin until absorbed.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com