



Derma IQ Skin Relief Toner
II-10.110.01A

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	92.62
A	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	0.50
B	Butylene Glycol	Butylene Glycol	Merck	3.00
B	Euxyl PE 9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
B	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
C	Perfume Tilia WS	Fragrance	Voegele	0.08
				100.00

Operating Instructions

Add Sepimax to the water while stirring and stir for 10 minutes. Add B in this order and stir until uniform. Add C as desired.

Directions for use:

Swipe it over your face with cotton pad or gently pat it into your skin with hands.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com