



All-In-One Eye Firming Solution
II-10.355.02

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	85.94
A	A-Leen 5	Pentylene Glycol	Minasolve	5.00
B	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	0.50
C	MPC™ - Milk Peptide Complex	Whey Protein	CLR	0.50
C	JuvenEye CLR™	Bellis Perennis (Daisy) Flower Extract Hieracium Pilosella (Hawkweed) Extract	CLR	5.00
C	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
D	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.06
				100.00

Operating Instructions

Add B to premixed A while stirring. Add C and stir until homogeneous. Adjust pH value to 6.2-6.5 with D, if necessary.

Directions for use:

Roll on gently under the eye area before and after bedtime.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com