



HappyGlow Sparkling Body Mist  
II-14.385.03A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	81.30
A	Avicel PC 611	Microcrystalline Cellulose Cellulose Gum	DuPont	1.50
A	Amaze XT	Dehydroxanthan Gum	Nouryon	0.20
A	Perfume Moroccan Fig N32799	Fragrance	Carrubba	0.20
A	Pentylene Glycol	Pentylene Glycol	Cosnaderm	5.00
A	Zemea	Propanediol	DuPont Tate & Lyle	5.00
B	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
B	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.30
D	Sachet Opal Lemon Green	Synthetic Fluorophlogopite Titanium Dioxide Silica Tin Oxide Yellow 5 Lake	Sandream Specialties	0.15
D	Timica Silver Sparkle 5500	Mica Titanium Dioxide	Sun Chemical	0.35
				<b>100.00</b>

#### **Operating Instructions**

Disperse Avicel PC 611, perfume oil & Amaze XT into water using high shear (e.g. rotor-stator mixer for 5 minutes). Add B and adjust pH value to 5.5 with C. Add D and stir until uniform. (Anchor stirrer is recommended).

Directions for use:

Spray all over the parts of your body and enjoy a sparkling shimmer.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)