



Biotic Balance Face Serum  
II-14.431.02

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	77.84
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.20
A	Dissolvine GL-38	Tetrasodium Glutamate Diacetate Water Sodium Hydroxide	Nouryon	0.10
A	A-Leen 5	Pentylene Glycol	Minasolve	5.00
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	3.00
A	<b>MPC™ - Milk Peptide Complex</b>	Whey Protein	CLR	0.50
B	Rheocare XGN	Xanthan Gum	BASF	0.30
C	<b>Repair Complex CLR™ PF</b>	Bifida Ferment Lysate	CLR	5.00
C	<b>ProRenew Complex CLR™</b>	Lactococcus Ferment Lysate	CLR	3.00
C	<b>Phytosan™ K</b>	Water Glycerin Glycine Soja (Soybean) Seed Extract	CLR	5.00
D	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.01
E	Timica Brilliant White 020C	Mica Titanium Dioxide	BASF	0.05
				<b>100.00</b>

**Operating Instructions**

Mix A and stir until completely dispersed. Add B and stir until uniform. Add C in this order. Adjust pH value to 6-7 with D. Add E as desired.

Directions for use:

Apply in the morning and evening on cleansed skin before your usual routine.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)