



Come As You Are - Pore Treatment Roll-On  
II-19.136.03A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	94.94
A	Viscarin PC 209	Carrageenan	DuPont	1.00
B	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.90
B	<b>CutiFine CLR™</b>	Water Gypsophila Vaccaria Flower/Leaf/Stem Extract Adansonia Digitata Pulp Extract	CLR	3.00
B	Perfume Tilia WS	Fragrance	Voegele	0.10
C	Citric Acid (50%)	Citric Acid Water	N.A.	0.06
				<b>100.00</b>

#### ***Operating Instructions***

Mix A and stir until completely dispersed. Add B in this order and stir until uniform. Adjust pH value to 5.3 with C.

Directions for use:

Roll-on gently on desired area around the nose.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)