



Rich Collagen Face & Body Spray
II-23.352.04

| Phase | Material Name | US INCI | Supplier | % Material |
|--------------|-----------------------------|--|-----------------|-------------------|
| A | Deionized Water | Water | N.A. | 73.63 |
| A | Tylose H 4070 NG4 | Hydroxyethylcellulose | Shin-Etsu | 0.10 |
| B | Butylene Glycol | Butylene Glycol | Merck | 5.00 |
| B | Glycerin 86% | Glycerin Water | Gustav Heess | 3.00 |
| B | Trisodium Citrate Dihydrate | Sodium Citrate | Merck | 0.27 |
| B | Pentylene Glycol | Pentylene Glycol | Cosnaderm | 5.00 |
| C | Maricol S | Soluble Collagen | CLR | 10.00 |
| C | MultiMoist CLR™ | Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water | CLR | 3.00 |
| | | | | 100.00 |

Operating Instructions

Mix A and add B and C in this order. Stir until homogenous with moderate stirring.

Directions for use:

Spray all over the face/body and massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com