



Vitalizing Toner 40+
II-31.352.01A

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	82.58
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	1.00
A	Pentylene Glycol	Pentylene Glycol	Cosnaderm	5.00
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	3.00
B	Maricol S	Soluble Collagen	CLR	5.00
B	Phytosan™ K	Water Glycerin Glycine Soja (Soybean) Seed Extract	CLR	3.00
C	Rheocare XGN	Xanthan Gum	BASF	0.15
D	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.12
E	Perfume Black Bamboo WS	Fragrance	Voegele	0.15
				100.00

Operating Instructions

Add A and stir until uniform. Add B in this order and stir until uniform. Add C and stir until homogeneous. Adjust pH value to 6-6.5 with D, if necessary. Add E as desired.

Directions for use:

Take a few drops of the essence and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com