



Eyelash Serum  
II-34.176.01A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	87.94
A	Di-Sodium Hydrogen Phosphate Anhydrous	Sodium Phosphate	Merck	0.03
A	Zemea	Propanediol	Primient Covation LLC	5.00
A	Euxyl PE 9010	Phenoxyethanol Ethylhexylglycerin	Ashland	0.80
A	<b>Follicusan™ DP</b>	Water Alcohol Denat. Panthenyl Ethyl Ether Milk Protein Lactose Inositol Acetyl Cysteine Acetyl Methionine Sodium Citrate Citric Acid	CLR	5.00
A	Citric Acid (10%)	Water Citric Acid	N.A.	0.08
A	Aristoflex AVC	Ammonium Acryloyldimethyltaurate/VP Copolymer	Clariant	1.00
A	Perfume Aloe Flower KWS	Fragrance	Frey+Lau	0.15
				<b>100.00</b>

#### *Operating Instructions*

Mix A in this order and stir until homogeneous.

Directions for use:

Apply directly on your upper lash line onto clean, makeup free skin and eyelashes every night before bedtime.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)