



Refreshing Eyes Tonic
II-37.290.01A

| <i>Phase</i> | <i>Material Name</i> | <i>US INCI</i> | <i>Supplier</i> | <i>% Material</i> |
|--------------|-----------------------------|----------------------------------------------------------------------------------|-----------------|-------------------|
| A | Deionized Water | Water | N.A. | 87.02 |
| A | Trisodium Citrate Dihydrate | Sodium Citrate | Merck | 0.30 |
| A | LaraCare A200 | Galactoarabinan | Lonza | 0.50 |
| B | Oramix CG 110 | Caprylyl/Capryl Glucoside | SEPPIC | 0.50 |
| B | DayMoist CLR™ | Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract | CLR | 3.00 |
| B | JuvenEye CLR™ | Bellis Perennis (Daisy) Flower Extract Hieracium Pilosella (Hawkweed) Extract | CLR | 3.00 |
| B | A-Leen 5 | Pentylene Glycol | Minasolve | 5.00 |
| C | NaOH (10%) | Water Sodium Hydroxide | N.A. | 0.48 |
| D | Perfume Grape PMF WS | Fragrance | Voegele | 0.20 |
| | | | | 100.00 |

Operating Instructions

Mix A and stir until uniform. Add B to A in this order with stirring. Adjust pH value to 5.5-6 with C. Add D as desired.

Directions for use:

Apply the tonic on a cotton wool ball and sweep it across your closed eye. There is no need to rinse afterwards.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com