



Keep Your Balance Day Shot  
II-46.138.01A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	87.00
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	1.50
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.15
A	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	0.60
A	Euxyl K 900	Benzyl Alcohol Ethylhexylglycerin Tocopherol	Ashland	0.80
B	Oramix CG 110	Caprylyl/Capryl Glucoside	SEPPIC	0.70
B	Perfume Calypso	Fragrance	Voegele	0.15
C	<b>CutiGuard CLR™</b>	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
C	<b>ProRenew Complex CLR™</b>	Lactococcus Ferment Lysate	CLR	3.00
C	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
D	Puricolor Blue ABL9-X FDA (0.2%)	Water Acid Blue 9	BASF	0.10
				<b>100.00</b>

#### **Operating Instructions**

Mix A and stir until homogeneous. Premix B and add to A while stirring. Add C in this order. Stir until uniform and add D as desired. Adjust pH value to 5.3-5.5, if necessary.

Directions for use:

Take a few drops and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)