



Gentle Pore Refining Toner
II-47.148.01A

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	78.41
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	1.99
A	A-Leen 5	Pentylene Glycol	Minasolve	3.00
A	Zemea	Propanediol	DuPont Tate & Lyle	4.00
A	CutiFine CLR™	Water Vaccaria Segetalis (Cowherb) Extract Adansonia Digitata (Baobab) Pulp Extract	CLR	3.00
A	DayMoist CLR™	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	3.00
B	Keltrol T Plus	Xanthan Gum	CP Kelco	0.12
C	Mandelic Acid	Mandelic Acid	R.L. Chemical Industries Pvt.	3.00
D	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.30
D	SyriCalm™ CLR (PC)	Water Phragmites Communis Extract Poria Cocos Extract	CLR	3.00
E	Perfume Criste Marine PMF WS	Fragrance	Voegele	0.18
				100.00

Operating Instructions

Mix A and stir until uniform. Disperse B into phase A. Add C while stirring and adjust pH value to 3.5-4 with D. Add E as desired and stir until homogeneous.

Directions for use:

Moisten a cotton ball with the toner. Stroke over the face (except eye area) in the morning and preferably in the evening after cleaning. Always use SPF and limit sun exposure after using this product.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com