



Good Night Sleeping Mask
II-49.138.02A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	79.82
A	DUB DIOL	Methylpropanediol	Stearinerie Dubois	8.00
A	CutiGuard CLR™	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
A	Sepimax ZEN	Polyacrylate Crosspolymer-6	SEPPIC	1.06
A	Sepinov EMT 10	Hydroxyethyl Acrylate/Sodium Acryloyldimethyl Taurate Copolymer	SEPPIC	1.06
B	ProRenew Complex CLR™ NP	Lactococcus Ferment Lysate	CLR	3.00
B	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.80
B	G+C Complex CLR™	Bifida Ferment Lysate	CLR	3.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.02
D	Puricolor Red ARE 33 FDA (0.4%)	Water Acid Red 33	BASF	0.04
D	Perfume Cucumber Melon WS	Fragrance	Voegelé	0.20
				100.00

Operating Instructions

Mix A in this order and stir until homogenous. Add B in this order and stir until uniform. Adjust pH value to 5-5.5 with C. Add D as desired and stir.

Directions for use:

Spread onto face and wait until dry. Leave on over night and rinse off in the morning as desired.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com