



Rescue Me Pore Minimizing Essence
II-5.136.07

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	89.60
A	Keltrol T Plus	Xanthan Gum	CP Kelco	0.15
B	A-Leen 5	Pentylene Glycol	Minasolve	3.00
B	CutiFine CLR™	Water Gypsophila Vaccaria Flower/Leaf/Stem Extract Adansonia Digitata (Baobab) Pulp Extract	CLR	3.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
B	Dermosoft 700B	Levulinic Acid Sodium Levulinate Glycerin Water	Evonik	1.00
C	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.25
				100.00

Operating Instructions

Mix A and stir until uniform. Add B and stir until homogeneous. Adjust pH value to 4.8-5 with C.

Directions for use:

Distribute a small amount of essence onto your fingertips and gently spread the product onto your skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com