



Quick Lifting Ampoule Treatment
II-5.355.01_1

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	85.48
A	Pullulan	Pullulan	Hayashibara	1.00
A	Keltrol CG-F	Xanthan Gum	CP Kelco	1.00
A	Zemea	Propanediol	Primient Covation LLC	2.00
B	MPC™ - Milk Peptide Complex	Whey Protein	CLR	0.50
B	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.12
B	Deionized Water	Water	N.A.	9.38
C	Nipaguard SCP	Phenoxyethanol Sorbitan Caprylate	Clariant	0.50
D	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.02
				100.00

Operating Instructions

Mix A and stir well. Premix B and add it to A while stirring. Add C and adjust pH value to 6-6.5 with D if necessary.

Directions for use:

Take a few drops of the serum and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com