



Root in Serenity Scalp Serum  
II-69.385.01

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	81.23
A	Keltrol CG-T V [E]	Xanthan Gum	CP Kelco	0.17
A	A-Leen 5	Pentylene Glycol	Minasolve	4.00
B	Sophance LA-A	Glycolipids Sodium Lactate	Evonik	2.00
B	Rheance One	Glycolipids	Evonik	4.00
B	Dermosoft 1388 eco	Glycerin Water Sodium Levulinate Sodium Anisate	Evonik	1.50
B	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	1.00
B	<b>ProRenew Complex CLR™</b>	Lactococcus Ferment Lysate	CLR	3.00
B	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
C	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.10
				<b>100.000000</b>

#### ***Operating Instructions***

Mlx A and stir until uniform. Add B to A in this order one after another and stir. Adjust pH value to 5.4 with C, if necessary.

Directions for use:

Take a pea-sized amount and gently massage into the scalp.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)