



Anti-Aging Intensive Serum  
II-8.417.02

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	85.89
A	Keltrol CG-BT	Xanthan Gum	CP Kelco	0.20
B	Zemea	Propanediol	DuPont Tate & Lyle	4.00
B	EDETA B Powder	Tetrasodium EDTA	BASF	0.11
B	<b>Phytosan™ K</b>	Water Glycerin Glycine Soja (Soybean) Seed Extract	CLR	5.00
B	<b>Belides™ ORG</b>	Bellis Perennis (Daisy) Flower Extract	CLR	3.00
B	<b>DayMoist CLR™</b>	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	1.00
B	Microcare SB	Water Sodium Benzoate Potassium Sorbate	THOR	0.80
				<b>100.00</b>

**Operating Instructions**

Mix A and stir until homogeneous. Add B in this order. Mix until uniform.

Directions for use:

Take a few drops and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)