



Shine A Light Lip Gloss-Mauve\*  
IV-23.950.02

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Versagel ME 1600	Hydrogenated Polyisobutene Ethylene/Propylene/Styrene Copolymer Butylene/Ethylene/Styrene Copolymer	Calumet Penreco	72.49
A	Myritol 312 MB	Caprylic/Capric Triglyceride	BASF	8.00
A	Silshine 151	Phenylpropyldimethylsiloxysilicate	Momentive	5.00
A	Silsoft 034	Caprylyl Methicone	Momentive	4.00
B	SynCrystal Copper	Synthetic Fluorphlogopite Iron Oxides	Eckart	0.50
B	Mirage Blue	Calcium Sodium Borosilicate Titanium Dioxide Tin Oxide	Eckart	5.50
C	<b>Vitamin F forte</b>	Linoleic Acid Linolenic Acid	CLR	1.00
C	<b>PhytoDefense CLR™</b>	Glycine Soja (Soybean) Oil Dicaprylyl Ether Magnolia Grandiflora Bark Extract Lauryl Alcohol	CLR	3.00
C	Copherol F 1300 C	Tocopherol	BASF	0.11
C	Flavour Cherry		Pura Natura	0.40
				<b>100.000000</b>

#### **Operating Instructions**

Heat up A to 75°C. Add B and stir until uniform. Cool down to 40°C and add C in this order. Stir until homogeneous and pour into lip gloss container.

Directions for use:

Glide over lips with applicator for shiny glowing lips.

\*developed & produced by Eckart; [www.eckart.net](http://www.eckart.net)

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)