



Natural You Micelle Water  
V-1.385.01A

<b>Phase</b>	<b>Material Name</b>	<b>US INCI</b>	<b>Supplier</b>	<b>% Material</b>
A	Deionized Water	Water	N.A.	87.95
A	Perlastan SC 25 NKPF	Water Disodium Cocoyl Glutamate Sodium Cocoyl Glutamate	Schill & Seilacher	3.00
A	Dermosoft OMP	Methylpropanediol Caprylyl Glycol Phenylpropanol	Evonik	3.00
A	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
A	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
B	Perfume Black Bamboo WS	Fragrance	VOEGELE	0.05
				<b>100.00</b>

#### **Operating Instructions**

Mix A and stir until homogeneous. Add B as desired and stir.

Directions for use:

Apply the solution on a cotton wool ball and sweep it across your whole face. There is no need to rinse afterwards. Just enjoy the clean, fresh sensation.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)