



Female Cleansing Foam pH4
V-33.385.01

Phase	Material Name	US INCI	Supplier	% Material
A	Plantacare 818 UP	Coco-Glucoside	BASF	15.00
A	Lamesoft PO 65 MB	Coco-Glucoside Glyceryl Oleate	BASF	1.50
B	Deionized Water	Water	N.A.	78.10
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	1.00
B	SyriCalm™ CLR (PC)	Water Phragmites Communis Extract Poria Cocos Extract	CLR	3.00
B	Sodium Benzoate	Sodium Benzoate	Azelis	0.40
C	Lactic Acid (80%)	Lactic Acid Water	N.A.	1.00
				100.000000

Operating Instructions

Mix A and B separately. Add B to A and stir until uniform. Adjust pH value to 4 with C. Fill into pump foam dispenser.

Directions for use:

Apply a small amount to the genital area and rinse it off thoroughly.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com