



Gentle Exfoliating Facial Cleanser
V-5.148.01A

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	57.79
A	Amaze XT	Dehydroxanthan Gum	Nouryon	1.00
B	Ethanol (96%)	Alcohol	Berkel AHK	15.00
B	Glycerin 86%	Glycerin Water	Gustav Heess	5.00
B	Plantacare 2000 UP	Decyl Glucoside	BASF	6.00
B	Dehyton MC	Sodium Cocoamphoacetate	BASF	5.50
B	DayMoist CLR™	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	1.00
B	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.00
B	Citric Acid (50%)	Citric Acid Water	N.A.	0.51
C	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
D	ImerScrub 400P Gold	Perlite	Imerys	2.00
E	Grapefruit Oil	Citrus Paradisi Peel Oil	Voegele	0.20
				100.00

Operating Instructions

Mix A and stir until uniform. Add B in the given order with moderate stirring. Add C and stir until uniform. Slowly add D with moderate stirring. Add E as desired.

Directions for use:

Apply on the wet face, neck & décolleté. Avoid contact with area around the eyes. Massage thoroughly and rinse-off well. Use two to three times a week.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com