



Face Wash Gel for Radiant Skin

V-5.421.02_1

Phase	Material Name	US INCI	Supplier	% Material
A	Deionized Water	Water	N.A.	74.76
A	Glycerol 85%, vegetable Ph. Eur.	Glycerin	Gustav Heess	5.00
A	Amaze XT	Dehydroxanthan Gum	Nouryon	1.00
B	Dermosoft 1388 eco	Glycerin Water Sodium Levulinate Sodium Anisate	Evonik	3.00
B	ProRenew Complex CLR™	Lactococcus Ferment Lysate	CLR	3.00
B	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	1.00
B	Plantacare 2000 UP	Decyl Glucoside	BASF	6.00
B	Dehyton MC	Sodium Cocoamphoacetate	BASF	5.50
C	Lactic Acid (80%)	Lactic Acid Water	N.A.	0.74
				100.000000

Operating Instructions

Mix A and stir until uniform. Add B in this order and adjust pH value to 5 with C.

Directions for use:

Use twice a day, morning and night. Apply on face, neck & décolleté. Massage over face and other parts, avoiding eye area. Rinse thoroughly and pat skin dry.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com